




x1



x1



x1



x1



x2



x2



















x2


CR2032




x1





GB Optional features DE Optionale Funktionen
 FI Options disponibles NL Opties F Valinnaiset ominaisuudet
 OK Valgirie funktioner IT Funzionalità opzionali
 ES Opciones disponibles PT Funções opcionais
 GR Προαιρετικές λειτουργίες πρόσθετων SE Möjliga funktioner



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
GB	•	•					•	•
FI	•	•	•	•			•	•
OK	•	•	•	•	•	•	•	•



GB Linking DE Einlernen GR Programming
 NL Verknüpfung F Linkitminen OK Forbinde
 IT Collegamento ES Enlace
 PT Programação GR Συνέζηση SE Länkning



GB Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing
 FI Vianmääritys OK Problemløsning IT Risoluzione dei problemi ES Solución de
 problemas PT Resolução de problemas GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com

